



Nissan Navara D22 3.0L 1999-2015

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting pipe and flex join pipe from the vehicle.
3. Remove gear box bracket.
4. Unbolt the four tail shaft bolts and move tail shaft to the side.
5. Remove turbo dump pipe heat shield.
6. Remove turbo dump pipe. We advise to spray the 2 nuts and 3 bolts with WD40 before removing. Hint: It is sometimes easier to remove some of the nuts/bolts from underneath the vehicle.
7. Insert the supplied EGT plug into the turbo dump pipe.
8. Fit the turbo dump pipe section to the turbo outlet flange using the five supplied M8x1.25 nuts and three M8x1.25 studs. Tighten all 5 nuts.
9. Fit the front pipe section to the turbo dump pipe and tighten finger tight with the supplied 3/8 UNC nuts.
10. Re fit the tail shaft back into place using the four factory nuts and bolts.
11. Fit the cat/cat delete flex section to the front pipe and tighten finger tight with the supplied 3/8 UNC nuts.
12. Re fit the gear box bracket as per image 1 using the four supplied nyloc nuts, washers, and bolts and two of the factory gear box bolts.
13. Fit the pipe only/resonator or muffler section to the connecting pipe and tighten finger tight with the supplied 3/8 UNC nuts.
14. Fit the tailpipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts.



15. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
16. Enjoy your IGNITE exhaust!

Image 1.

