



## **Nissan Navara D23 NP300 2.3L 2015 onwards DPF model**

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting and DPF pipe from the vehicle.
3. Using the factory DPF flange nuts and supplied 4mm adaptor plate with 2.5" gasket fit the DPF pipe and tighten finger tight.
4. Fit the pipe only/resonator or muffler section to the DPF pipe and tighten finger tight with the supplied 3/8 UNC nuts.
5. Fit the tailpipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts.
6. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
7. Enjoy your IGNITE exhaust!