



RG Holden Colorado 2012-2016 NON DPF model

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting pipe from the vehicle.
3. Remove flex join pipe from the vehicle.
4. Remove turbo dump pipe heat shield.
5. Remove gear box bracket.
6. Remove turbo dump pipe. We advise to spray the 4 nuts with WD40 before removing.
7. Insert the supplied EGT plug into the turbo dump pipe.
8. Fit the turbo dump pipe cat/cat delete section to the turbo outlet flange using the four supplied M8x1.25 nuts. Re fit gear box bracket at the same time and then tighten all 4 nuts.
9. Fit the flex join pipe to the turbo dump pipe cat/cat delete section and tighten finger tight with the supplied 3/8 UNC nuts.
10. Fit the connecting pipe to the flex pipe and tighten finger tight with the supplied 3/8 UNC nuts.
11. Fit the pipe only/resonator or muffler section to the connecting pipe and tighten finger tight with the supplied 3/8 UNC nuts. (Fit diff pipe section in the same format if that's what you purchased and then continue with step 13)
12. Fit the tailpipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts.
13. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
14. Enjoy your IGNITE exhaust!