



## **Toyota Landcruiser 79 series 4.5L DPF model 2015 onwards**

1. Remove rear tail pipe and muffler assembly from the vehicle.
2. Remove centre connecting and DPF pipe from the vehicle whilst also removing the O2 sensor.
3. Using the factory DPF spring loaded bolts fit the DPF pipe and tighten finger tight. Also fit the rectangular mounting plates on top of the exhaust hanger mounts with the x2 10mm nuts finger tight on top.
4. Screw in the O2 sensor and tighten.
5. Fit the connecting pipe to the DPF pipe and tighten finger tight with the supplied 3/8 UNC nuts. Also fit the rectangular mounting plates on top of the exhaust hanger mounts with the x2 10mm nuts finger tight on top.
6. Fit the pipe only/resonator or muffler section to the connecting pipe and tighten finger tight with the supplied 3/8 UNC nuts.
7. Fit the tailpipe to the pipe only/resonator or muffler section and tighten finger tight with the supplied 3/8 UNC nuts. Also fit the rectangular mounting plates on top of the exhaust hanger mounts with the x2 10mm nuts finger tight on top.
8. Check over exhaust making sure everything is aligned and then tighten all bolts and nuts from the front to back of the vehicle.
9. Enjoy your IGNITE exhaust!